

# Spot98 PLUS

DIGITAL HEAT TRANSFERS



*Iron-On  
Heat Transfers  
for*

**DARK COLORS**

*Jersey Knit  
Textile Fabric  
T-Shirts  
& Other  
Textile Fabrics*

## APPLICATION SETTINGS

	HEAT PRESS	HOME IRON	
PRESSURE	HIGH	HIGH	
TEMPERATURE	200 C / 390 F	200 C / 390 F	
TIME	60 SECONDS	80 SECONDS	
RUB	As it cools to cold	As it cools to cold	

## Instructions

- Iron the area where you will be printing the graphic to remove moisture and wrinkles.
- Cut out the transfer paper around the graphic and Peel OFF the transfer backing paper.
- Place the cut-out graphic transfer where you will be printing on the t-shirt.
- WITH THE GRAPHIC SIDE FACING UP - TRANSFER PAPER BACKSIDE FACING DOWN.
- Cover the Graphic transfer on the t-shirt with TEFLON SHEET ( or Kraft Paper ).
- Iron / Press / Print it as the APPLICATION SETTINGS above.
- Rub it with a cloth as it cools to cold.
- Remove Teflon Sheet ( or Kraft Paper ) in an even upward motion 2 O'clock direction.

### Wash & Dry Recommendation

► Up to 40° C (cold wash cycle).

USE THE **FREE** TESTER TO PRACTICE BEFORE PRINTING ON YOUR OWN T-SHIRTS