

Spot98

DIGITAL HEAT TRANSFERS

Custom Iron-Os



Full Color
Digital Iron-On
Of Your Designs

ID:0551

*Iron-On
Heat Transfers
for
WHITE COLOR
Jersey Knit
Textile Fabric
T-Shirts
& Other
Textile Fabrics*

APPLICATION SETTINGS

	HEAT PRESS	HOME IRON	
PRESSURE	HIGH	HIGH	
TEMPERATURE	200 C / 390 F	200 C / 390 F	
TIME	10-15 Seconds	25-30 Seconds	
RUB	10 Seconds	10 Seconds	

Instructions

- Iron the area where you will be printing the graphic to remove moisture and wrinkles.
- Cut out the transfer paper around the graphic in a normal shape (oval, rectangle, etc).
- Place the cut-out graphic transfer where you will be printing on the t-shirt.
- WITH THE GRAPHIC SIDE FACING DOWN - TRANSFER PAPER BACKSIDE FACING UP.
- Place teflon sheet (or Kraft Paper) over the graphic transfer.
- Iron/ Print it as the APPLICATION SETTINGS above.
- Rub it with a cloth for about 10 seconds.
- Remove the Telfon Sheet (or Kraft Paper) in an even upward motion 2 o'clock direction.

Wahs & Dry Recommendation

▶ Up to 40° C (cold wash cycle).

USE THE **FREE** TESTER TO PRACTICE BEFORE PRINTING ON YOUR OWN T-SHIRTS