

Spot98

Nylon Transfers



SpotNylon Application

SpotNylon Iron-On Material

Application

HEAT APPLICATIONS:

Preheat Garment

TIME: 10-15 seconds

TEMPERATURE: 320° F/160° C

PRESSURE: light

Peel HOT

ADHERES TO:

nylon

leather