

SpotDeco Heat Transfers Application Instructions

SpotDeco Material iron-on heat transfers are professional grade Heat Transfers made from specialty materials. They come ready to apply on a carrier sheet. You simply weed out the un-wanted material and print them. They are quality tested on a regular basis, durable and machine washable after they are printed. Cold wash and hang to dry recommended.

They print on all fabric colors and work well on Cotton, Polyester and Blend Fabrics. They are also available for low heat sensitive fabrics like Nylon (see products info).

Please use the free tester we send you with your order to practice the application if you need, before you start printing on your clothing.

These transfers are quick and simple to apply, only the designs left on the carrier sheet transfers to the shirt.

1. Weed out the material you DO NOT want to print on the shirt (note that some come weeded already). Leave what you want to print on the shirt attached to the carrier sheet.
2. Iron and smooth the area where you will be printing to remove any moisture and wrinkles from the shirt.
3. Position the transfer on the shirt FACING UP.
4. Use the application settings below to use a Home Iron or Heat Press Machine to print them on shirts. These settings are based on the equipment we used to test them, we used a standard home iron and a manual heat press machine. You may need to make final adjustments according to the equipment you are using. For this, use the free tester we sent you.



Home Hand Iron and Heat Press Machine

Temperature Setting: 320°-350° Fahrenheit / 160°-177° Celsius

Press Time: Press the transfer for 10-15 seconds.

Downward Force: Medium

**RUB IT WITH A CLOTH AS IT COOLS AND PEEL WARM
DO NOT LET IT COOL COMPLETELY**

With FLOCK Material press longer for 15-20 seconds and PEEL COLD.

With Glitter, Transparents and Gloss Materials PEEL COLD.

Watch Videos Online